

## Lanyard Attachment Instructions

The SEEK TIC's integrated lanyard loop is not durable enough for fire fighting environments.

A lanyard attachment utilizing a D-ring and integrated mounting holes provides a solid attachment point. The Adhesive Pad Eye controls

the hanging orientation of the camera.



1. Attach D-ring w/ screws

- 2. Clean housing with alcohol swab
- 3. Attach Pad Eye with Adhesive Pad as pictured at right.

Note: Attach to plastic housing, avoiding rubber pad.

4. Allow adhesive to set for 12 hours







**To Install:** Hold Gear Keeper in palm of one hand and catch metal *Tang* on belt and spread belt clip to clear metal *Catch*. Be sure *Catch* fully clears belt.

**To Remove:** Hold Gear Keeper in palm of one hand and spread belt clip to clear *Catch*.


Use other hand to push *Tang* down to clear belt and remove.

**Warning:** Avoid opening Belt Clip more than 1/2 " to prevent loss of clip memory.





- A. Slide Moveable Loop up against Fixed Loop; then feed Velcro Strap through Retainer and back up through Moveable Loop.
- B. Pull up on Velcro Strap so that loops cinch down on Retainer.
- C. Feed Velcro Strap around belt or belt loop; then back through Fixed Loop.
- D. Affix Velcro Strap back on itself.







## **Phone Attachment Instructions**


**Option 1** Mount directly to phone or smooth case surface with **3M® Adhesive Pad Eye** mount —

## **Attach Pad Eye to Surface**

- 1 Clean surface and pad eye with alcohol swab
- 2 Attach pad eye with adhesive and press firmly
- **3** Adhesive bond strength increases over time. For best results, install 24 hours prior to use (bond strength 50% after 20 minutes, 90% after 24 hours).

**Option 2** Attach to lanyard loop on phone case as

shown here.



WARNING: If mounting to a phone case, insure the case is substantial enough such that phone will not fall out if dropped.



## **Belt Clip Attachment Instructions**



Catch



DON'T Stop Here

**To Install:** Hold Gear Keeper in palm of one hand and catch metal *Tang* on belt and spread belt clip to clear metal *Catch*. Be sure *Catch* fully clears belt.

**To Remove:** Hold Gear Keeper in palm of one hand and spread belt clip to clear *Catch*. Use other hand to push *Tang* down to clear belt and remove.

Warning: Avoid opening Belt Clip more than 1/2 " to prevent loss of clip memory.

WARNING: Avoid opening clip more than 1/2" to prevent loss of clip memory.



5720 Nicolle St. Ventura, CA 93003 (888) 588-9981 / (805) 658-9922 www.gearkeeper.com info@gearkeeper.com